

Praxair Material Safety Data Sheet

1. Chemical Product and Company Identification

Product Name: Ethylene Oxide/Carbon Dioxide Mixture	Trade Name: Ethylene Oxide/Carbon Dioxide Mixture
Product Use: Many.	
Chemical Name: Not applicable.	Synonym: Sterilant Mixtures
Chemical Formula: Mixtures of ethylene oxide & carbon dioxide (9.1-58.39% Ethylene oxide)	Chemical Family: Not applicable.
Telephone: Emergencies: * 1-800-363-0042	Supplier /Manufacture: Praxair Canada Inc. 1 City Centre Drive Suite 1200 Mississauga, ON L5B 1M2 Phone: 905-803-1600 Fax: 905-803-1682

**Call emergency numbers 24 hours a day only for spills, leaks, fire, exposure, or accidents involving this product. For routine information, contact your supplier or Praxair sales representative.*

2. Composition and Information on Ingredients

INGREDIENTS	% (VOL)	CAS NUMBER	LD ₅₀ (Species & Routes)	LC ₅₀ (Rat, 4 hrs.)	TLV-TWA (ACGIH)
Ethylene Oxide	9.1 - 58.39	75-21-8	72 mg/kg	1462 ppm	1 ppm
Carbon dioxide	41.61 - 90.9	124-38-9	Not available.	Not available.	5000 ppm

3. Hazards Identification

Emergency Overview

DANGER! Cancer hazard and reproductive hazard. Toxic, extremely flammable liquid and gas under pressure. Can form explosive mixtures with air. Can cause eye and skin burns. Can irritate the respiratory tract. May cause nervous system damage and cataracts. Liquid may cause frostbite. May cause dizziness and drowsiness. Symptoms of exposure may be delayed. Self-contained breathing apparatus must be worn by rescue workers. Ethylene oxide is highly reactive.

ROUTES OF EXPOSURE:

Absorbed through skin. Eye contact. Inhalation. Ingestion.

EFFECTS OF A SINGLE (ACUTE) OVEREXPOSURE:

INHALATION:

Asphyxiant. Moderate concentrations may cause headaches, drowsiness, dizziness, stinging of the nose and throat, excitation, rapid breathing, excess salivation, vomiting, and unconsciousness. Lack of oxygen can kill. Causes irritation of the respiratory tract. Carbon Dioxide is also a physiological active, affecting circulation and breathing. Depending on the degree of exposure, there may be coughing, chest tightness, nausea, diarrhea, weakness, cyanosis, loss of coordination, convulsions and coma. May cause lung injury and the delayed onset of pulmonary edema.

SKIN CONTACT: With liquid or solutions in water, there may occur a local erythema, edema, and formation of vesicles. There may be a latent period of several hours prior to the onset of these signs. Liquid may cause frostbite.

SKIN ABSORPTION: Sustained contact with the skin is unlikely, but can cause headache, dizziness, nausea and vomiting. A dilute solution may penetrate skin, producing, a chemical burn.

SWALLOWING: A highly unlikely route of exposure. Will cause severe irritation and ulceration of the mouth and throat, abdominal pain, nausea, vomiting, collapse and coma. Frostbite of the lips and mouth may result from contact with the liquid.

EYE CONTACT: Liquid may cause frostbite and severe irritation with corneal injury. Moderate irritation from high concentrations of vapour.

EFFECTS OF REPEATED (CHRONIC) OVEREXPOSURE:

Ethylene Oxide: Allergic contact dermatitis may occur in a small proportion of exposed workers. In various reports involving recurrent exposures to high concentrations of ethylene oxide vapour, peripheral neurotoxic effects, and, in some cases, indications of central nervous system toxicity, where described resulting from gross overexposure. In most cases, there was marked improvement on removal from further exposure. A few cases of cataract formation have increased incidence of abortions, the laboratory findings indicated that if adverse reproductive effects are produced by ethylene oxide, these occur only at high exposure concentrations. Several studies on ethylene oxide exposed workers have demonstrated an increased incidence of chromosomal aberrations and sister chromatic exchanges; the relevance of such effects to human health hazards evaluation is currently uncertain. OSHA considers that, at excess levels, Ethylene Oxide may present reproductive, mutagenic, genotoxic, neurologic and sensitization hazards.

Carbon Dioxide: No harm expected.

OTHER EFFECTS OF OVEREXPOSURE:

Ethylene Oxide: May cause cataracts.

Carbon Dioxide: Damage to retinal ganglion cells and central nervous system may occur.

MEDICAL CONDITIONS AGGRAVATED BY OVEREXPOSURE:

The toxicology and the physical and chemical properties of this product suggest that overexposure is unlikely to aggravate medical condition.

SIGNIFICANT LABORATORY DATA WITH POSSIBLE RELEVANCE TO HUMAN HEALTH HAZARD EVALUATION:

Ethylene Oxide: This component has been shown to produce mutagenic and cytogenic effects in a variety of test systems. Animals exposed to ethylene oxide vapour for up to two years have shown an increase in the incidence of certain malignant tumors in comparison to nonexposed controls.

In humans, an increased occurrence of leukemia and stomach cancer has been reported by one group of investigators who pooled results from three Swedish facilities producing or using ethylene oxide, among other materials. Based on experimental and observational data ethylene oxide is a suspect cancer hazard, and should be treated as possible causing cancer in humans. Laboratory studies with mice have shown that acute exposure to ethylene oxide vapour at concentrations of 30 ppm and above cause testicular injury as evidenced by concentrations-related increased embryonic deaths following the mating of exposed males to nonexposed females (Dominant Lethal Test). A recently completed NIOSH study of sterilant workers found an elevated risk of blood cancers among men and breast cancers among women. The elevated risk occurred only at high exposures as defined by a combination of exposure level and years worked. The study showed no elevated cancer or disease risk for sterilant workers overall as compared to the general U.S. population.

In a developmental toxicity study with rats exposed to 225, 125, or 50 ppm of ethylene oxide vapor, there was maternal toxicity at 225 ppm and at 125 ppm. Fetotoxicity was present as reduced fetal body weight at all concentrations, and increased incidents of skeletal variants at 225 ppm indications of embryotoxicity or malformations. In a two-generation oxide vapor for 6 hr/day, 5 day/week, there was parental toxicity at 33 and 100 ppm. Postimplant losses with reduction

in litter size and offspring bodyweight were present at 33 and 100 ppm. The no-observed-effects concentrations for adult toxicity, offspring effects, and reproductive effects was 10 ppm.

Carbon Dioxide: A single study has shown an increase in heart defects in rats exposed to 6% carbon dioxide in air for 24 hours at different times during gestation. There is no evidence that carbon dioxide is tetragenetic in humans.

CARCINOGENICITY:

Ethylene Oxide: OSHA considers ethylene oxide to pose a human cancer hazard and a human reproductive hazard. The IARC assigns it to Group 1, "Carcinogenic to humans". The NTP classifies it as "Known to be a human carcinogen".

4. First Aid Measures

INHALATION:

If inhaled, remove to fresh air. If not breathing, give artificial respiration. If breathing is difficult, give oxygen. Get medical attention.

SKIN CONTACT:

Immediately flush affected areas with water for at least 15 minutes while removing contaminated clothing and shoes. Wash with soap and water. For exposure to liquid, immediately warm frostbite area with warm water not to exceed 105°F (41°C). In case of massive exposure, remove contaminated clothing while showering with warm water. Call a physician. Aerate, wash or clean contaminated clothing. Discard leather goods or shoes.

SWALLOWING:

Give two glasses of water. Do not induce vomiting. Call a physician.

EYE CONTACT:

Immediately flush eyes with water for a least 15 minutes. See a physician, preferably an ophthalmologist, immediately

NOTES TO PHYSICIAN:

IMPORTANT: In all cases of exposure, get or summon medical treatment immediately. Take victim to a doctor or medical facility at once.

(1) Persons exposed to ethylene oxide may develop severe and intractable vomiting, requiring the use of antiemetics given intravenously. (2) Prolonged or high vapour concentrations exposure may result in the development of pulmonary edema after a latent phase of several hours. Also, respiratory tract injury caused by ethylene oxide may predispose to the development of a secondary respiratory infraction. Individuals exposed to moderately high vapour concentrations of ethylene oxide should be retained for observation. (3) Following skin contamination, primary irritation and blister formation may be delayed in onset. (4) When introduced directly into the blood stream ethylene oxide may act as a hapten and lead to the development of anaphylactoid reactions of varying severity. This have been noted in a few haemodialysis and plasmapheresis patients due to desorption of ethylene oxide from the sterilized equipment. There appears to be a close association to the presence of IgE antibodies to albumin/ethylene oxide conjugates.

5. Fire Fighting Measures

FLAMMABLE : Yes. **IF YES, UNDER WHAT CONDITIONS?** Forms explosive mixtures with air and oxidizing agents.

FLASH POINT (test method) Not applicable. **AUTOIGNITION TEMPERATURE** Not applicable.

FLAMMABLE LIMITS IN AIR, % by volume: **LOWER:** 3% **UPPER:** 100% (Ethylene Oxide)

EXTINGUISHING MEDIA:
CO2, dry chemical, water spray or fog.

SPECIAL FIRE FIGHTING PROCEDURES:

DANGER! Evacuate all personnel from danger area. Immediately cool cylinders with water spray from maximum distance taking care not to extinguish flames. Remove ignition source if without risk. If flames are accidentally extinguished, explosive re-ignition may occur; therefore, appropriate measures should be taken; e.g., total evacuation. Re-approach with extreme caution. Use self-contained breathing apparatus. Stop flow of gas if without risk while continuing cooling water spray. Remove all containers from area if without risk. Allow fire to burn out.

UNUSUAL FIRE AND EXPLOSION HAZARD:

Flammable gas. Forms explosive mixtures with air and oxidizing agents. Container may rupture due to heat of fire. Do not extinguish flames due to possibility of explosive re-ignition. Flammable vapours may spread and spill. Explosive atmospheres may linger. Before entering area, especially confined areas, check atmosphere with approved device. No part of a container should be subjected to temperature higher than 52 C (approximately 125 F). Vapours form from this product and may travel or be moved by air currents and ignited by pilot lights, other flames, smoking, sparks, heaters, electrical equipment, static discharges, or other ignition sources at locations distant from product handling point. Most containers are provided with a pressure relief device designed to vent contents when they are exposed to elevated temperature.

HAZARDOUS COMBUSTION PRODUCTS:

These products are carbon oxides (CO, CO₂).

SENSITIVITY TO IMPACT:

Avoid impact against container.

SENSITIVITY TO STATIC DISCHARGE:

Possible, ground container.

6. Accidental Release Measures

STEPS TO BE TAKEN IF MATERIAL IS RELEASED OR SPILLED:

DANGER! Forms explosive mixtures with air. Immediately evacuate all personnel from danger area. Use self-contained breathing apparatus operated in the pressure demand mode and appropriate protective clothing. Remove all sources of ignition if without risk. Reduce vapours with fog or fine water spray. Shut off leak if without risk. Ventilate area of leak or move leaking container to well ventilated area. Flammable vapours may spread from spill. Before entering area, especially confined areas, check atmosphere with appropriate device.

WASTE DISPOSAL METHOD:

Prevent waste from contaminating the surrounding environment. Keep personnel away. Discard any product, residue, disposable container, or liner in an environmentally acceptable manner, in full compliance with federal, provincial, and local regulations. If necessary, call your local supplier for assistance.

7. Handling and Storage

PRECAUTIONS TO BE TAKEN IN STORAGE:

Store and use with adequate ventilation. Separate flammable cylinders from oxygen, chlorine, and other oxidizers by at least 20 ft. (6.1 m) or use a barricade of non-combustible material. This barricade should be at least 5 ft (1.53 m) high and have a fire resistance rating of at least ½ hour. Firmly secure cylinders upright to keep them from falling or being knocked over. Screw valve protection cap firmly in place by hand. Post "No Smoking or Open Flames" signs in storage and use areas. There must be no sources of ignition. All electrical equipment in storage areas must be explosion-proof. Storage areas must meet national electric codes for Class 1 hazardous areas. Store only where temperature will not exceed 125°F (52°C). Store full and empty cylinders separately. Use a first-in, first-out inventory system to prevent storing full cylinders for long periods.

PRECAUTIONS TO BE TAKEN IN HANDLING:

Protect cylinders from damage. Use a suitable hand truck to move cylinders; do not drag, roll, slide, or drop. Electrical equipment must be non-sparking or explosion-proof. Leak check system with soapy water; never use a flame. Never attempt to lift a cylinder by its cap; the cap is intended solely to protect the valve. Never insert an object (e.g., wrench, screwdriver, pry bar) into cap openings; doing so may damage the valve and cause a leak. Use an adjustable strap wrench to remove over-tight or rusted caps. Open valve slowly. If valve is hard to open, discontinue use and contact your supplier. For other precautions, see section 16.

For additional information on storage and handling, refer to Compressed Gas Association (CGA) pamphlet P-1, *Safe Handling of Compressed Gases in Containers*, available from the CGA. Refer to section 16 for the address and phone number along with a list of other available publications.

OTHER HAZARDOUS CONDITIONS OF HANDLING, STORAGE, AND USE:

Flammable high-pressure gas. Use only in a closed system. Use piping and equipment adequately designed to withstand pressures to be encountered. Use only spark-proof tools and explosion-proof equipment. Keep away from heat, sparks and flame. **Gas can cause rapid suffocation due to oxygen deficiency.** Store and use with adequate ventilation. Close valve after each use; keep closed even when empty. **Prevent reverse flow.** Reverse flow into cylinder may cause rupture. Use a check valve or other protective device in any line or piping from the cylinder. **Never work on a pressurized system.** If there is a leak, close the cylinder valve. Blow the system down in an environmentally safe manner in compliance with all federal, provincial, and local laws, then repair the leak. **Never place a compressed gas cylinder where it may become part of an electrical circuit.**

8. Exposure Controls/Personal Protection

VENTILATION/ENGINEERING CONTROLS:

LOCAL EXHAUST: An explosion-proof local exhaust system is acceptable. See SPECIAL.

MECHANICAL (general): Inadequate. See SPECIAL.

SPECIAL: Use only in a closed system. Ventilation should be designed in such a manner that no person is exposed to concentrations of ethylene oxide exceeding the TLV of 1ppm.

OTHER: See SPECIAL.

PERSONAL PROTECTION:

RESPIRATORY PROTECTION: Use respirable fume respirator or air supplied respirator when working in confined space or where local exhaust or ventilation does not keep exposure below TLV. Select in accordance with the provincial regulations or guidelines. Selection should also be based on the current CSA standards Z94.4, "Selection, care and use of respirators". Respirators should be approved by NIOSH and MSHA.

SKIN PROTECTION: Butyl rubber. Gloves have a lifetime of approximately one half to one hour after contact with liquid ethylene oxide.

EYE PROTECTION: Wear safety glasses when handling cylinders.

Select in accordance with the current CSA standard Z94.3, "Industrial Eye and Face Protection", and any provincial regulations, local bylaws or guidelines.

OTHER PROTECTIVE EQUIPMENT: Metatarsal shoes for cylinder handling. Protective clothing where needed. Cuffless trousers should be worn outside the shoes. Select in accordance with the current CSA standard Z195, "Protective Foot Wear", and any provincial regulations, local bylaws or guidelines.

9. Physical and Chemical Properties

PHYSICAL STATE: Gas.	FREEZING POINT: -112.6°C (-170.7°F) based on data for: Ethylene Oxide.	pH: Acidic.
BOILING POINT: Not available.	VAPOUR PRESSURE: 675-750 psig	MOLECULAR WEIGHT: Not applicable.
SPECIFIC GRAVITY: LIQUID (Water = 1) Weighted average: 1.52 (Water = 1)	SOLUBILITY IN WATER, Appreciable	
SPECIFIC GRAVITY: VAPOUR (air = 1) Not available.	EVAPORATION RATE (Butyl Acetate=1): >1 (Ethylene Oxide) compared to (Butyl Acetate=1)	COEFFICIENT OF WATER/OIL DISTRIBUTION: Not available.
VAPOUR DENSITY: The highest known value is >1 (Air = 1) (Carbon dioxide). Weighted average: 1.1 (Air = 1)	% VOLATILES BY VOLUME: 100%	ODOUR THRESHOLD: Not available.

APPEARANCE & ODOUR: Colourless. Odour: Ethereal.

10. Stability and Reactivity

STABILITY:	The product is stable.
CONDITIONS OF CHEMICAL INSTABILITY:	Pure Ethylene Oxide will decompose violently if exposed to a high enough temperature, commonly accepted to be above 560 C at atmospheric pressure. This temperature can vary depending upon time, pressure, and conditions of the system. The temperature required for decomposition is reduced as pressure and volume-to-surface ratios are increased. Ethylene Oxide is stable at ordinary conditions of temperatures and pressure and in ordinary use, handling and storage.
INCOMPATIBILITY (materials to avoid):	Oxidizers, mecaptans, alkali metals, alkaline earth metals, alcohols, metal acetylides, chromium, titanium above 550 C, uranium above 750 C.
HAZARDOUS DECOMPOSITION PRODUCTS:	Thermal decomposition or burning may produce carbon monoxide/carbon dioxide.
HAZARDOUS POLYMERIZATION:	Yes.
CONDITIONS OF REACTIVITY:	Trace polymers may be present under ordinary conditions of temperature, pressure, etc. However, Ethylene Oxide will polymerize violently if contaminated with aqueous alkalies, amines, mineral acids, metal chlorides or metal oxides. Avoid exposing stored cylinders to heat or sources of ignition.

11. Toxicological Information

See section 3.

Carbon Dioxide Component: Carbon dioxide is an asphyxiant. It initially stimulates respiration and then causes respiratory depression. High concentrations result in narcosis. Symptoms in humans are as follows:

Table with 2 columns: EFFECTS and CO2 CONCENTRATION. Rows describe symptoms like 'Breathing rate increases slightly' at 1% concentration, 'Breathing rate increases to 50% above normal level' at 2%, 'Breathing increases to twice normal rate' at 3%, 'Breathing increases to approximately four times normal rate' at 4-5%, 'Characteristic sharp odor noticeable' at 5-10%, and 'Unconsciousness occurs more rapidly above 10% level' at 10-100%.

12. Ecological Information

No adverse ecological effects expected. This product does not contain any Class I or Class II ozone-depleting chemicals. The components of this mixture are not listed as marine pollutants by TDG Regulations.

13. Disposal Considerations

WASTE DISPOSAL METHOD: Do not attempt to dispose of residual or unused quantities. Return cylinder to supplier.

14. Transport Information

TDG/IMO SHIPPING NAME: ETHYLENE OXIDE AND CARBON DIOXIDE MIXTURES (with more than 9 percent but not more than 87 percent ethylene oxide).

Table with 3 columns: HAZARD CLASS (Class 2.1: Flammable gas), IDENTIFICATION # (UN1041), and PRODUCT REPORTABLE QUANTITY (PRQ) (Any accidental release in a quantity that could pose a danger to public safety or any sustained release of 10 minutes or more).

SHIPPING LABEL(s): Flammable gas

PLACARD (when required): Flammable gas

SPECIAL SHIPPING INFORMATION:

Cylinders should be transported in a secure position, in a well-ventilated vehicle. Cylinders transported in an enclosed, non-ventilated compartment of a vehicle can present serious safety hazards.

15. Regulatory Information

The following selected regulatory requirements may apply to this product. Not all such requirements are identified. Users of this product are solely responsible for compliance with all applicable federal, provincial, and local regulations.

DSL (Canada)	This product is on the DSL list
WHMIS (Canada)	Class A: Compressed gas. Class B-1: Flammable gas. Class D-1A: Material causing immediate and serious toxic effects (VERY TOXIC). Class D-2A: Material causing other toxic effects (VERY TOXIC). Class D-2B: Material causing other toxic effects (TOXIC). Class F: Dangerously reactive material.

International Regulations

EINECS	Not available.
DSCL (EEC)	R20- Harmful by inhalation. R45- May cause cancer. R46- May cause heritable genetic damage. R60- May impair fertility.

International Lists No products were found.

16. Other Information

MIXTURES:

When two or more gases, or liquefied gases are mixed, their hazardous properties may combine to create additional, unexpected hazards. Obtain and evaluate the safety information for each component before you produce the mixture. Consult an Industrial Hygienist, or other trained person when you make your safety evaluation of the end product. Remember, gases and liquids have properties which can cause serious injury or death.

HAZARD RATING SYSTEM:

HMIS RATINGS:

HEALTH 1 *

FLAMMABILITY 4

PHYSICAL HAZARD 3

*An Asterisk used in conjunction with HMIS health hazards ratings designates a carcinogenic or reproductive hazard.

STANDARD VALVE CONNECTIONS FOR U.S. AND CANADA:

THREADED:	CGA-350
PIN-INDEXED YOKE:	Not applicable.
ULTRA-HIGH-INTEGRITY CONNECTION:	Not applicable.

Use the proper CGA connections. **DO NOT USE ADAPTERS.** Additional limited-standard connections may apply. See CGA pamphlets V-1 and V-7 listed below.

Ask your supplier about free Praxair safety literature as referred to in this MSDS and on the label for this product. Further information about this product can be found in the following pamphlets published by the Compressed Gas Association, Inc. (CGA), 4221 Walney Road, 5th Floor, Chantilly, VA 20151-2923, Telephone (703) 788-2700, Fax (703) 961-1831, website: www.cganet.com.

Product Name: Ethylene Oxide/Carbon
Dioxide Mixture

MSDS# E-4705-N

Date: Oct. 15, 2013

AV-1 Safe Handling and Storage of Compressed Gas
G-6 Carbon Dioxide
G-6.1 Standard for Low Pressure Carbon Dioxide Systems at Customer Sites
G-6.2 Commodity Specification for Carbon Dioxide
P-1 Safe Handling of Compressed Gases in Containers
P-14 Accident Prevention in Oxygen-Rich, Oxygen-Deficient Atmospheres
SB-2 Oxygen-Deficient Atmospheres
V-1 Compressed Gas Cylinder Valve Inlet and Outlet Connections
V-7 Standard Method of Determining Cylinder Valve Outlet Connections for Industrial Gas Mixtures
--- Handbook of Compressed Gases, Fifth Edition

For more indepth information for each component, refer to the pure product MSDS.

The information contained in this MSDS is generated from technical sources using the Chemmate Mixture MSDS system and the pure-product MSDS for each component. These mixtures are not tested as a whole for chemical, physical, or health effects.

PREPARATION INFORMATION:

DATE: October 15, 2013
DEPARTMENT: Safety and Environmental Services
TELEPHONE: 905-803-1600

The opinions expressed herein are those of qualified experts within Praxair Canada Inc. We believe that the information contained herein is current as of the date of this Material Safety Data Sheet. Since the use of this information and the conditions of use of the product are not within the control of Praxair Canada Inc., it is the user's obligation to determine the conditions of safe use of the product.

Praxair Canada Inc. requests the users of this product to study this Material Data Sheet (MSDS) and become aware of product hazards and safety information. To promote safe use of this product, a user should (1) notify its employees, agents and contractors of the information on this MSDS and any product hazards and safety nformation, (2) furnish this same information to each of its customers for the product, and (3) request such customers to notify their employees and customers for the product of the same product hazards and safety information.

*Praxair and the Flowing Airstream design are trademarks of
Praxair Canada Inc.*

Other trademarks used herein are trademarks or registered trademarks of their respective owners.



Praxair Canada Inc.
1 City Centre Drive
Suite 1200
Mississauga, ON L5B 1M2